

INDUSTRIAL

AIR COMPRESSOR

PARTS MANUAL

NAPA AIR COMPRESSORS

QD Quiet Power

NAPA Air Compressors


Service and Support: 866-869-3114

Rev811

Table of Contents

Page	Contents
1.	30 Gallon Gas Drive Parts Breakdown
2.	Quiet Power Parts Breakdown
3.	Quiet Power Parts List
4.	5 HP Vertical Parts Breakdown
5.	5 HP Vertical Parts List
6.	5 HP Horizontal Parts Breakdown
7.	5 HP Horizontal Parts List
8.	7.5 HP Vertical Parts Breakdown
9.	7.5 HP Vertical Parts List
10.	7.5 HP Horizontal Parts Breakdown
11.	7.5 HP Horizontal Parts List
12.	10 HP Vertical Parts Breakdown
13.	10 HP Vertical Parts List
14.	10 HP Horizontal Parts Breakdown
15.	10 HP Horizontal Parts List
16.	Duplex Parts Breakdown
17.	Duplex Parts List
18.	QP Pump (824116090019) Parts Breakdown
19.	QP Pump (824116090019) Parts List
20.	5 HP Pump (821312202800) Parts Breakdown
21.	5 HP Pump (821312202800) Parts List
22.	7.5 - 10 HP Pump (821312202700) Parts Breakdown
23.	7.5 - 10 HP Pump (821312202700) Parts List
Back Cover	Warranty Statement


Gas Drive Compressors



III. No.	Part Description	Model 821033GTH	Model 821133GTV	Model 821633GT
1	Compressor	821312202800	821312202800	821312202700
2	Engine	821312100223	821312100730	821312100731
3	Tank	821312201400	821312201400	821312201400
4	Unloader Valve	821312100497	821312100497	821312100497
5	Safety Valve	829710533300	829710533300	829710533300
6	Press. Gauge	821312100378	821312100378	821312100378
7	Disch. Tube	821312100716	821312100716	821312100720
8	Ball Valve	821312100162	821312100162	821312100162
9	Tank Drain	821312100360	821312100360	821312100360
10	Belt Guard	821312204300	821312204300	821312204300
	Belt x 2	821312100721	821312100721	821312100736
	Idle Control	821312100382	821312100741	821312100741
	Drive Pulley	821312100711	821312100711	821312100711

Part Numbers Subject to Change without Notice

Pump Breakdown is located on Page 20 of this Manual






III. No.	Part Description	Model QP581VAT	Model QP583VAT	Model QP7581VAT	Model QP7583VAT
1	Compressor	824116090019	824116090019	824116090019	824116090019
2	Motor	821312100399	821312101602	821312100400	821312101601
3	Tank	821312104600	821312104600	821312104600	821312104600
4	Check Valve	821312100169	821312100169	821312100169	821312100169
5	Press. Switch	821312100570	821312100570	821312100570	821312100570
6	Safety Valve	829710533300	829710533300	829710533300	829710533300
7	Press. Gauge	821312100378	821312100378	821312100378	821312100378
8	Mag. Starter	821312100659	821312100656	821312100662	821312100658
9	Canopy	821312202180	821312202180	821312202180	821312202180
10	Tank Drain	821312100110	821312100110	821312100110	821312100110
11	Ball Valve	821312100163	821312100163	821312100163	821312100163
12	Disch. Tube	821312100198	821312100198	821312100198	821312100198
13	Inlet Filter	821312100097	821312100097	821312100097	821312100097
14	Low Oil Switch	821312100014	821312100014	821312100014	821312100014
15	Blower	821312100088	821312100088	821312100088	821312100088
16	Belt Guard	821312100148	821312100148	821312100148	821312100148
		821312100150	821312100150	821312100150	821312100150
	Belt	821312100140	821312100140	821312100139	821312100139
	Belt Guard Clip	821312100076	821312100076	821312100076	821312100076
	Unloader Line	821312100373	821312100373	821312100373	821312100373
	Drive Pulley	821312100422	821312100422	821312100420	821312100420
	High Temp Switch	821312100089	821312100089	821312100089	821312100089

Part Numbers Subject to Change without Notice

Pump Breakdown is located on Page 18 of this Manual

5 HP Vertical Models



5HP Vertical Parts List


III. No.	Part Description	Model 82348VAT208	Model 82348VAT	Model 82348VATK	Model 82348VATFF	Model 82348VBT
1	Compressor	821312202800	821312202800	821312202800	821312202706	821312202800
2	Motor	821312100399	821312100399	821312100399	821312100399	821312101602
3	Tank	821312201200	821312201200	821312201200	821312201200	821312201200
4	Belt x 2	821312100724	821312100724	821312100724	821312100724	821312100724
5	Press. Switch	821312100570	821312100570	821312100570	821312100570	821312100570
6	Safety Valve	829710533300	829710533300	829710533300	829710533300	829710533300
7	Press. Gauge	821312100028	821312100028	821312100028	821312100028	821312100028
8	Mag. Starter	821312100659	821312100659	821312100659	821312100659	821312100656
9	Tank Drain	821312100360	821312100360	821312100110	821312100110	821312100360
10	Disch. Tube	821312100719	821312100719	821312100719	821312100340	821312100719
11	Belt Guard	821312204400	821312204400	821312204400	821312204400	821312204400
	Low Oil Switch	NA	NA	821312100014	821312100014	NA
	Belt Guard Aftercooler	NA	NA	NA	821312100611	NA
	Check Valve	821312100171	821312100171	821312100171	821312100167	821312100171
	Unloader Line	821312100026	821312100026	821312100373	821312100373	821312100026
	Drive Pulley	821312100714	821312100714	821312100714	821312100714	821312100714

III. No.	Part Description	Model 82348VBT460	Model 82348VBTK	Model 82348VBTK460	Model 82348VBTKFF	Model 82348VBTKFF460
1	Compressor	821312202800	821312202800	821312202800	821312100706	821312100706
2	Motor	821312101602	821312101602	821312101602	821312101602	821312101602
3	Tank	821312201200	821312201200	821312201200	821312201200	821312201200
4	Belt x 2	821312100724	821312100724	821312100724	821312100724	821312100724
5	Press. Switch	821312100570	821312100570	821312100570	821312100570	821312100570
6	Safety Valve	829710533300	829710533300	829710533300	829710533300	829710533300
7	Press. Gauge	821312100028	821312100028	821312100028	821312100028	821312100028
8	Mag. Starter	821312100654	821312100656	821312100654	821312100656	821312100654
9	Tank Drain	821312100360	821312100110	821312100110	821312100110	821312100110
10	Disch. Tube	821312100719	821312100719	821312100719	821312100340	821312100340
11	Belt Guard	821312204400	821312204400	821312204400	821312204400	821312204400
	Low Oil Switch	NA	821312100014	821312100014	821312100014	821312100014
	Belt Guard Aftercooler	NA	NA	NA	821312100611	821312100611
	Check Valve	821312100171	821312100171	821312100171	821312100167	821312100167
	Unloader Line	821312100026	821312100373	821312100373	821312100373	821312100373
	Drive Pulley	821312100714	821312100714	821312100714	821312100714	821312100714

Part Numbers Subject to Change without Notice

Pump Breakdown is located on Page 20 of this Manual

5 HP Horizontal Models




5HP Horizontal Parts List

III. No.	Part Description	Model 82348HAT208	Model 82348HAT	Model 82348HBT	Model 82348HBT460
1	Compressor	821312202800	821312202800	821312202800	821312202800
2	Motor	821312100399	821312100399	821312101602	821312101602
3	Tank	821312201300	821312201300	821312201300	821312201300
4	Belt x 2	821312100724	821312100724	821312100724	821312100724
5	Press. Switch	821312100570	821312100570	821312100570	821312100570
6	Safety Valve	829710533300	829710533300	829710533300	829710533300
7	Press. Gauge	821312100378	821312100378	821312100378	821312100378
8	Mag. Starter	821312100659	821312100659	821312100656	821312100654
9	Tank Drain	821312100360	821312100360	821312100360	821312100360
10	Disch. Tube	821312100719	821312100719	821312100719	821312100719
11	Belt Guard	821312204400	821312204400	821312204400	821312204400
	Check Valve	821312100171	821312100171	821312100171	821312100171
	Unloader Line	821312100026	821312100026	821312100026	821312100026
	Drive Pulley	821312100714	821312100714	821312100714	821312100714
III. No.	Part Description	Model 82349HAT208	Model 82349HAT	Model 82349HBT	Model 82349HBT460
1	Compressor	821312202800	821312202800	821312202800	821312202800
2	Motor	821312100399	821312100399	821312101602	821312101602
3	Tank	821312203000	821312203000	821312203000	821312203000
4	Belt x 2	821312100724	821312100724	821312100724	821312100724
5	Press. Switch	821312100570	821312100570	821312100570	821312100570
6	Safety Valve	829710533300	829710533300	829710533300	829710533300
7	Press. Gauge	821312100378	821312100378	821312100378	821312100378
8	Mag. Starter	821312100659	821312100659	821312100656	821312100654
9	Tank Drain	821312100360	821312100360	821312100360	821312100360
10	Disch. Tube	821312100719	821312100719	821312100719	821312100719
11	Belt Guard	821312204400	821312204400	821312204400	821312204400
	Check Valve	821312100171	821312100171	821312100171	821312100171
	Unloader Line	821312100026	821312100026	821312100026	821312100026
	Drive Pulley	821312100714	821312100714	821312100714	821312100714

Part Numbers Subject to Change without Notice

Pump Breakdown is located on Page 20 of this Manual

7.5 HP Vertical Models




7.5HP Vertical Parts List

III. No.	Part Description	Model 82378VAT208	Model 82378VAT	Model 82378VATK	Model 82378VATFF	Model 82378VBT
1	Compressor	821312202700	821312202700	821312202700	821312202700	821312202700
2	Motor	821312100394	821312100394	821312100394	821312100394	821312101601
3	Tank	821312201200	821312201200	821312201200	821312201200	821312201200
4	Belt x 2	821312100722	821312100722	821312100722	821312100722	821312100722
5	Press. Switch	821312100570	821312100570	821312100570	821312100570	821312100570
6	Safety Valve	829710533300	829710533300	829710533300	829710533300	829710533300
7	Press. Gauge	821312100028	821312100028	821312100028	821312100028	821312100028
8	Mag. Starter	821312100662	821312100662	821312100662	821312100662	821312100658
9	Tank Drain	821312100360	821312100360	821312100110	821312100110	821312100360
10	Disch. Tube	821312100717	821312100717	821312100717	821312100340	821312100717
11	Belt Guard	821312204400	821312204400	821312204400	821312204400	821312204400
	Low Oil Switch	NA	NA	821312100014	821312100014	NA
	Belt Guard Aftercooler	NA	NA	NA	821312100611	NA
	Check Valve	821312100172	821312100172	821312100172	821312100172	821312100172
	Unloader Line	821312100026	821312100026	821312100026	821312100026	821312100026
	Drive Pulley	821312100712	821312100712	821312100712	821312100712	821312100712
III. No.	Part Description	Model 82378VBTK	Model 82378VBTF	Model 82378VBT460	Model 82378VBTF460	
1	Compressor	821312202700	821312202700	821312202700	821312202700	
2	Motor	821312101601	821312101601	821312101601	821312101601	
3	Tank	821312201200	821312201200	821312201200	821312201200	
4	Belt x 2	821312100722	821312100722	821312100722	821312100722	
5	Press. Switch	821312100570	821312100570	821312100570	821312100570	
6	Safety Valve	829710533300	829710533300	829710533300	829710533300	
7	Press. Gauge	821312100028	821312100028	821312100028	821312100028	
8	Mag. Starter	821312100658	821312100658	821312100657	821312100657	
9	Tank Drain	821312100110	821312100110	821312100360	821312100110	
10	Disch. Tube	821312100717	821312100340	821312100717	821312100340	
11	Belt Guard	821312204400	821312204400	821312204400	821312204400	
	Low Oil Switch	821312100014	821312100014	NA	821312100014	
	Belt Guard Aftercooler	NA	821312100611	NA	821312100611	
	Check Valve	821312100172	821312100172	821312100172	821312100172	
	Unloader Line	821312100026	821312100026	821312100026	821312100026	
	Drive Pulley	821312100712	821312100712	821312100712	821312100712	

Part Numbers Subject to Change without Notice

Pump Breakdown is located on Page 22 of this Manual

7.5HP Horizontal Models




7.5HP Horizontal Parts List

III. No.	Part Description	Model 82378HAT208	Model 82378HAT	Model 82378HBT	Model 82378HBT460
1	Compressor	821312202700	821312202700	821312202700	821312202700
2	Motor	821312100394	821312100394	821312101601	821312101601
3	Tank	821312201300	821312201300	821312201300	821312201300
4	Belt x 2	821312100722	821312100722	821312100722	821312100722
5	Press. Switch	821312100570	821312100570	821312100570	821312100570
6	Safety Valve	829710533300	829710533300	829710533300	829710533300
7	Press. Gauge	821312100378	821312100378	821312100378	821312100378
8	Mag. Starter	821312100662	821312100662	821312100658	821312100657
9	Tank Drain	821312100360	821312100360	821312100360	821312100360
10	Disch. Tube	821312100717	821312100717	821312100717	821312100717
11	Belt Guard	821312204400	821312204400	821312204400	821312204400
	Check Valve	821312100172	821312100172	821312100172	821312100172
	Unloader Line	821312100026	821312100026	821312100026	821312100026
	Drive Pulley	821312100712	821312100712	821312100712	821312100712
III. No.	Part Description	Model 82379HAT208	Model 82379HAT	Model 82379HBT	Model 82379HBT460
1	Compressor	821312202700	821312202700	821312202700	821312202700
2	Motor	821312100394	821312100394	821312101601	821312101601
3	Tank	821312203000	821312203000	821312203000	821312203000
4	Belt x 2	821312100722	821312100722	821312100722	821312100722
5	Press. Switch	821312100570	821312100570	821312100570	821312100570
6	Safety Valve	829710533300	829710533300	829710533300	829710533300
7	Press. Gauge	821312100378	821312100378	821312100378	821312100378
8	Mag. Starter	821312100662	821312100662	821312100658	821312100657
9	Tank Drain	821312100360	821312100360	821312100360	821312100360
10	Disch. Tube	821312100717	821312100717	821312100717	821312100717
11	Belt Guard	821312204400	821312204400	821312204400	821312204400
	Check Valve	821312100172	821312100172	821312100172	821312100172
	Unloader Line	821312100026	821312100026	821312100026	821312100026
	Drive Pulley	821312100712	821312100712	821312100712	821312100712

Part Numbers Subject to Change without Notice

Pump Breakdown is located on Page 22 of this Manual

10HP Vertical Models



10HP Vertical Parts List


III. No.	Part Description	Model 82308VBT	Model 82308VBTK	Model 82308VBT460	Model 82308VBTK460	Model 82309VBT
1	Compressor	821312202700	821312202700	821312202700	821312202700	821312202700
2	Motor	821312101600	821312101600	821312101600	821312101600	821312101600
3	Tank	821312201200	821312201200	821312201200	821312201200	821312202900
4	Belt x 2	821312100723	821312100723	821312100723	821312100723	821312100723
5	Press. Switch	821312100570	821312100570	821312100570	821312100570	821312100570
6	Safety Valve	829710533300	829710533300	829710533300	829710533300	829710533300
7	Press. Gauge	821312100028	821312100028	821312100028	821312100028	821312100028
8	Mag. Starter	821312100661	821312100661	821312100657	821312100657	821312100661
9	Tank Drain	821312100360	821312100110	821312100360	821312100110	821312100360
10	Disch. Tube	821312100717	821312100717	821312100717	821312100717	821312100717
11	Belt Guard	821312204400	821312204400	821312204400	821312204400	821312204400
	Low Oil Switch	NA	821312100014	NA	821312100014	NA
	Belt Guard Aftercooler	NA	NA	NA	NA	NA
	Check Valve	821312100172	821312100172	821312100172	821312100172	821312100172
	Unloader Line	821312100026	821312100026	821312100026	821312100026	821312100026
	Drive Pulley	821312100713	821312100713	821312100713	821312100713	821312100713

III. No.	Part Description	Model 82309VBTK	Model 82309VBT460	Model 82309VBTK460	Model 82309VBTF	Model 82309VBTF460
1	Compressor	821312202700	821312202700	821312202700	821312202700	821312202700
2	Motor	821312101600	821312101600	821312101600	821312101600	821312101600
3	Tank	821312202900	821312202900	821312202900	821312202900	821312202900
4	Belt x 2	821312100723	821312100723	821312100723	821312100723	821312100723
5	Press. Switch	821312100570	821312100570	821312100570	821312100570	821312100570
6	Safety Valve	829710533300	829710533300	829710533300	829710533300	829710533300
7	Press. Gauge	821312100028	821312100028	821312100028	821312100028	821312100028
8	Mag. Starter	821312100661	821312100657	821312100657	821312100661	821312100657
9	Tank Drain	821312100110	821312100360	821312100110	821312100110	821312100110
10	Disch. Tube	821312100717	821312100717	821312100717	821312100340	821312100340
11	Belt Guard	821312204400	821312204400	821312204400	821312204400	821312204400
	Low Oil Switch	821312100014	NA	821312100014	821312100014	821312100014
	Belt Guard Aftercooler	NA	NA	NA	821312100611	821312100611
	Check Valve	821312100172	821312100172	821312100172	821312100167	821312100167
	Unloader Line	821312100026	821312100026	821312100026	821312100026	821312100026
	Drive Pulley	821312100713	821312100713	821312100713	821312100713	821312100713

Part Numbers Subject to Change without Notice

Pump Breakdown is located on Page 22 of this Manual

10HP Horizontal Models



10HP Horizontal Parts List


III. No.	Part Description	Model 82308HBT	Model 82308HBTK	Model 82308HBT460	Model 82308HBTK460	Model 82309HBT
1	Compressor	821312202700	821312202700	821312202700	821312202700	821312202700
2	Motor	821312101600	821312101600	821312101600	821312101600	821312101600
3	Tank	821312201300	821312201300	821312201300	821312201300	821312203000
4	Belt x 2	821312100723	821312100723	821312100723	821312100723	821312100723
5	Press. Switch	821312100570	821312100570	821312100570	821312100570	821312100570
6	Safety Valve	829710533300	829710533300	829710533300	829710533300	829710533300
7	Press. Gauge	821312100378	821312100378	821312100378	821312100378	821312100378
8	Mag. Starter	821312100661	821312100661	821312100657	821312100657	821312100661
9	Tank Drain	821312100360	821312100110	821312100360	821312100110	821312100360
10	Disch. Tube	821312100717	821312100717	821312100717	821312100717	821312100717
11	Belt Guard	821312204400	821312204400	821312204400	821312204400	821312204400
	Low Oil Switch	NA	821312100014	NA	821312100014	NA
	Belt Guard Aftercooler	NA	NA	NA	NA	NA
	Check Valve	821312100172	821312100172	821312100172	821312100172	821312100172
	Unloader Line	821312100026	821312100026	821312100026	821312100026	821312100026
	Drive Pulley	821312100713	821312100713	821312100713	821312100713	821312100713

III. No.	Part Description	Model 82309HBTK	Model 82309HBT460	Model 82309HBTK460	Model 82309HBTFF	Model 82309VBTF460
1	Compressor	821312202700	821312202700	821312202700	821312202700	821312202700
2	Motor	821312101600	821312101600	821312101600	821312101600	821312101600
3	Tank	821312203000	821312203000	821312203000	821312203000	821312203000
4	Belt x 2	821312100723	821312100723	821312100723	821312100723	821312100723
5	Press. Switch	821312100570	821312100570	821312100570	821312100570	821312100570
6	Safety Valve	829710533300	829710533300	829710533300	829710533300	829710533300
7	Press. Gauge	821312100378	821312100378	821312100378	821312100378	821312100378
8	Mag. Starter	821312100661	821312100657	821312100657	821312100661	821312100657
9	Tank Drain	821312100110	821312100360	821312100110	821312100110	821312100110
10	Disch. Tube	821312100717	821312100717	821312100717	821312100340	821312100340
11	Belt Guard	821312204400	821312204400	821312204400	821312204400	821312204400
	Low Oil Switch	821312100014	NA	821312100014	821312100014	821312100014
	Belt Guard Aftercooler	NA	NA	NA	821312100611	821312100611
	Check Valve	821312100172	821312100172	821312100172	821312100167	821312100167
	Unloader Line	821312100026	821312100026	821312100026	821312100026	821312100026
	Drive Pulley	821312100713	821312100713	821312100713	821312100713	821312100713

Part Numbers Subject to Change without Notice

Pump Breakdown is located on Page 22 of this Manual

Duplex Models




Duplex Parts List

III. No.	Part Description	Model 822349HAT208	Model 822349HAT	Model 822349HBT	Model 822349HBT460	Model 822379HAT208	Model 822379HAT
1	Compressor	821312202800	821312202800	821312202800	821312202800	821312202700	821312202700
2	Motor	821312100399	821312100399	821312101602	821312101602	821312100394	821312100394
3	Tank	821312203100	821312203100	821312203100	821312203100	821312203100	821312203100
4	Belt	821312100724	821312100724	821312100724	821312100724	821312100722	821312100722
5	Press. Switch	821312100570	821312100570	821312100570	821312100570	821312100570	821312100570
6	Safety Valve	829710533300	829710533300	829710533300	829710533300	829710533300	829710533300
7	Press. Gauge	821312100028	821312100028	821312100028	821312100028	821312100028	821312100028
8	Mag. Starter	821312100659	821312100659	821312100656	821312100654	821312100662	821312100662
9	Tank Drain	821312100360	821312100360	821312100360	821312100360	821312100360	821312100360
10	Disch. Tube (Right)	821312100716	821312100716	821312100716	821312100716	821312100717	821312100717
	Disch. Tube (Left)	821312100719	821312100719	821312100719	821312100719	821312100717	821312100717
11	Belt Guard (Right)	821312204300	821312204300	821312204300	821312204300	821312204300	821312204300
	Belt Guard (Left)	821312204400	821312204400	821312204400	821312204400	821312204400	821312204400
	Alternator Housing	821312100113	821312100113	821312100113	821312100113	821312100113	821312100113
	Alternator Relay	821312100111	821312100111	821312100111	821312100112	821312100111	821312100111
	Check Valve	821312100171	821312100171	821312100171	821312100171	821312100172	821312100172
	Unloader Line	821312100026	821312100026	821312100026	821312100026	821312100026	821312100026
	Drive Pulley	821312100714	821312100714	821312100714	821312100714	821312100712	821312100712
III. No.	Part Description	Model 822379HBT	Model 822379HBT460	Model 822309HBT	Model 822309HBT460	Model 822300HBT	Model 822300HBT460
1	Compressor	821312202700	821312202700	821312202700	821312202700	821312202700	821312202700
2	Motor	821312101601	821312101601	821312101600	821312101600	821312101600	821312101600
3	Tank	821312203100	821312203100	821312203100	821312203100	821312201700	821312201700
4	Belt	821312100722	821312100722	821312100723	821312100723	821312100723	821312100723
5	Press. Switch	821312100570	821312100570	821312100570	821312100570	821312100570	821312100570
6	Safety Valve	829710533300	829710533300	829710533300	829710533300	829710533300	829710533300
7	Press. Gauge	821312100028	821312100028	821312100028	821312100028	821312100028	821312100028
8	Mag. Starter	821312100658	821312100657	821312100661	821312100657	821312100661	821312100657
9	Tank Drain	821312100360	821312100360	821312100360	821312100360	821312100360	821312100360
10	Disch. Tube (Right)	821312100717	821312100717	821312100717	821312100717	821312100717	821312100717
	Disch. Tube (Left)	821312100717	821312100717	821312100717	821312100717	821312100717	821312100717
11	Belt Guard (Right)	821312204300	821312204300	821312204300	821312204300	821312204300	821312204300
	Belt Guard (Left)	821312204400	821312204400	821312204400	821312204400	821312204400	821312204400
	Alternator Housing	821312100113	821312100113	821312100113	821312100113	821312100113	821312100113
	Alternator Relay	821312100111	821312100112	821312100111	821312100112	821312100111	821312100112
	Check Valve	821312100172	821312100172	821312100172	821312100172	821312100172	821312100172
	Unloader Line	821312100026	821312100026	821312100026	821312100026	821312100026	821312100026
	Drive Pulley	821312100712	821312100712	821312100713	821312100713	821312100713	821312100713

Part Numbers Subject to Change without Notice

Compressor Pump

824116090019



QD Quiet Power

Ill No.	Part No.	Qty.	Description
1	822236100833	6	Head Bolt (M10 x 80)
2	822236109236	1	Head Bolt (M10 x 80)
3	822236102019	1	Inlet Filter Elbow
4	829107264	2	Inlet Elbow to Head Bolt (M10 x 20)
8	826210717100	2	Valve Plate
9	826231646400	1	Cylinder Gasket
10	826222924600	1	Cylinder
11	822236100656	6	Cylinder Bolt (M10 x 30)
12	822236100653	13	Bearing Housing Bolt (M10 x 25)
13	822236100784	6	Cylinder Bolt Washer
14	826222018800	1	Bearing Housing - Non-Drive Side
15	826231647200	2	Bearing Housing Gasket
18	82D003023	1	Crankcase
19	822236102992	1	Oil Sight Glass
20	822236103001	1	Oil Fill Plug
21	822236100855	4	Conrod Nut (M8 x 1)
21-1	822236100745	4	Conrod Washer
21-2	826222629500	2	Connecting Rod
23	826214834800	2	Main Bearing (6206)
24	826214341600	1	Oil Seal
25	826222018600	1	Bearing Housing - Drive Side
26	826224019300	1	Flywheel
27	826214242700	1	Flywheel Washer
28	826211848500	1	Flywheel Bolt (M10 x 30 Left Hand Thread)
29	826212863100	1	Crankshaft
31	829107794	4	Conrod Bolt (M8 x 45)
32	826214342100	4	Wrist Pin Cirdip
33	826222726400	1	HP Wrist Pin
34	826222726500	1	LP Wrist Pin
35	826212864200	1	LP Piston
36	826212863800	1	HP Piston
37	822901323007	1	HP Ring Set
38	822901323008	1	LP Ring Set
39	826243732300	1	Intercooler
39-1	822236102026	1	Intercooler Cap Gasket
39-2	82D030010	1	Intercooler Cap
40	826231646200	1	Crankcase Gasket
41	822236108777	1	Valve Plate Gasket
42	826231646100	1	Head Gasket
43	826231648300	3	Cooler O-Ring
45	822236102031	1	Oil Breather Gasket
46	826214340900	1	Oil Breather
47	829101174	2	Oil Breather Bolt
47-1	822236102028	1	Aftercooler Top Cap Gasket
47-2	822236102012	1	Aftercooler Top Cap
47-3	822236102030	1	Aftercooler Bottom Cap Gasket
47-4	822236102013	1	Aftercooler Bottom Cap
48	826222726100	4	Connecting Rod Insert (Half)
50	821312100456	1	Aftercooler Safety Valve (1/4" NPT 225 psi)
51	826243731700	1	Aftercooler
56	821312100097	1	Inlet Filter Assembly
56-1	82FE004	1	Filter Element
58	821312100323	1	Oil Drain Plug (3/8" NPT)
60	829107241	14	Cooler Cap Bolt (M6 x 20)
61	821000135	14	Cooler Cap Nut

Available Kits


822901324723	Valve Kit
821000806K	Gasket Kit
82A032039K	Overhaul Kit

Compressor Pump 824116090019



Compressor Pump

821312202800




Compressor Pump 821312202800

Item	Description	Qty	Part #				
1	Crankcase	1	821312100876	39	Nut - Hex M16	1	820261111403
2	Crank Shaft C1	1	821312100932	40	Gasket - Cylinder to Crankcase	1	821312100914
3	Fly Wheel C1	1	821312100884	41	Capscrew-Hex M10x30	6	820147136303
4	Cylinder C1	1	821312100880	42	Copper Gasket 10	6	821312100923
5	Head C1	1	821312100878	43	Aftercooler	1	821312100875
6	Oil Sight Glass	1	821312100903	44	Gasket Valve Cover	3	821312100919
7	Oil Drain Pipe	1	821312100859	45	Elbow - Street	2	821312100865
8	Oil Drain Pipe Cap	1	821312100861	46	Valve Assy HP Inlet	1	821312100891
9	Oil Fill Elbow	1	821312100933	47	Safety Valve 250 psi	1	821312100862
10	Plug	4	821312100866	48	Gasket Aftercooler	2	821312100918
11	Spacer - Inlet Valve C1	2	821312100893	49	Elbow Aftercooler	1	821312100873
12	Spacer Discharge Valve	3	821312100894	50	Gasket - Cylinder Head C1	1	821312100913
13	Breather Body	1	821312100934	51	Capscrew - Skt HD M8x30	2	820211132603
14	Copper Connector	1	821312100860	52	Capscrew - Skt HD M8x25	2	820211132503
15	Copper Nut	2	821312100856	53	Lockwasher 12	8	820333223600
16	Cover-Centrifugal Unloader	1	821312100899	54	Capscrew-Hex M12x70	8	820147140903
17	Valve Assy HP/LP Discharge	2	821312100892	55	Gasket Intercooler	2	821312100927
18	Retainer Inlet Valve C1	1	821312100898	56	Cover Valve	3	821312100897
19	Capscrew-Hex M8x25	21	820147132503	57	Safety Valve 75 psi	1	821312100889
20	Lockwasher 8	8	820333222500	58	Capscrew-Hex M8x90	4	820147133803
21	Retainer Inlet Valve C1	1	821312100895	59	Copper Gasket B8	7	821312100924
22	Gasket Rear Cap	1	821312100920	60	Intercooler C1	1	821312100871
23.1	Shim 0.20 Brg. Adj.	1	821312100930	61	Aluminum Tube 10x380	1	821312100863
23.2	Shim 0.10 Brg. Adj.	2	821312100929	62	Filter Inlet Assembly C1	1	821312100374
24	Retainer Discharge Valve	3	821312100896	63	Filter Replacement Element	1	821312100881
25	Copper Elbow	1	821312100857	64	Connecting Rod C1	2	821312100869
26	Gasket Side Cover	1	821312100916	65	Dipper-Oil C1	2	821312100870
27	Cover Crankcase Side	1	821312100858	66	Insert Half	4	821312100905
28	Copper Gasket	14	821312100921	67	Bearing- Wrist Pin Needle C1	2	821312100910
29	Gasket Front Cap	1	821312100915	68	Snap Ring - Internal	4	821312100867
30	Bearing Cap Rear C1	1	821312100909	69	Wrist Pin LP Piston C1	1	821312100901
31	Bearing Cone Rear C1	1	821312100908	70	Wrist Pin HP Piston C1	1	821312100902
32	Bearing Cone Front C1	1	821312100906	71	Piston-LP C1	1	821312100887
33	Bearing Cap Front C1	1	821312100907	72	Piston-HP C1	1	821312100888
34	Seal-Shaft C1	1	821312100911	73	Piston Ring Set- LP C1	1	821312100885
35	Cap Front C1	1	821312100868	74	Piston Ring Set- HP CA2	1	821312100886
36	Capscrew-Hex M16x120	1	820147149203	75	Copper Gasket - Valve Seat C1	5	821312100922
37	Key Fly Wheel C1	1	821312100928	76	Valve Assembly-LP Inlet C1	2	821312100890
38	Lockwasher 16	1	820333224300		Gasket Set	1	821312100925

Compressor Pump

821312202700



Compressor Pump 821312202700

Item	Description	Qty	Part #			
1	Crankcase	1	821312100877	40	Gasket - Cylinder to Crankcase	1
2	Crank Shaft C2	1	821312100931	41	Capscrew-Hex M10x30	12
3	Fly Wheel C2	1	821312100883	42	Copper Gasket 10	12
4	Cylinder C1	1	821312100880	43	Aftercooler C2	1
5.1	Head C1	1	821312100878	44	Gasket Valve Cover	6
5.2	Right Head C2	1	821312100879	45	Valve Assy HP Inlet	2
6	OIL SIGHT GLASS C1	1	821312100903	46	Safety Valve 250 psi	1
7	Oil Drain Pipe	1	821312100859	47	Gasket Aftercooler	4
8	Oil Drain Pipe Cap	1	821312100861	48	Elbow Aftercooler C2	2
9	Oil Fill Elbow	1	821312100933	49	Gasket - Cylinder Head C1	2
10	Plug	4	821312100866	50	Capscrew - Skt HD M8x30	4
11	Spacer - Inlet Valve C1	4	821312100893	51	Capscrew - Skt HD M8x25	4
12	Spacer Discharge Valve	6	821312100894	52	Lockwasher 12	16
13	Breather Body	1	821312100934	53	Capscrew-Hex M12x70	16
14	Copper Connector	1	821312100860	54	Gasket Intercooler	4
15	Copper Nut	2	821312100856	55	Reducing Bushing C1	2
16	Cover-Centrifugal Unloader	1	821312100899	56	Cover Valve	6
17	Gasket Unloader Cover	1	821312100912	57	Safety Valve 75 psi	2
18	Retainer Inlet Valve C1	3	821312100898	58	Capscrew-Hex M8x90	8
19	Capscrew-Hex M8x25	28	820147132503	59	Copper Gasket B8	14
20	Lockwasher 8	12	820333222500	60	Intercooler C1	2
21	Retainer Inlet Valve C1	1	821312100895	61	Aluminum Tube 10x380	1
22	Gasket Rear Cap	1	821312100920	62	Filter Inlet Assembly C1	2
23	Shim 0.20 Brg. Adj.	1	821312100930	63	Filter Replacement Element	2
23	Shim 0.10 Brg. Adj.	2	821312100929	64	Connecting Rod C1	4
24	Retainer Discharge Valve	6	821312100896	65	Dipper-Oil C1	4
25	Copper Elbow	1	821312100857	66	Insert Half	8
26	Gasket Side Cover C2	2	821312100917	67	Bearing- Wrist Pin Needle C1	4
27	Cover Crankcase Side C2	2	821312100904	68	Snap Ring - Internal	8
28	Copper Gasket 8	26	821312100921	69	Wrist Pin LP Piston C1	2
29	Gasket Front Cap C2	1	821312100915	70	Wrist Pin HP Piston C1	2
30	Bearing Cap Rear C1	1	821312100909	71	Piston-LP C1	2
31	Bearing Cone Rear C1	1	821312100908	72	Piston-HP C1	2
32	Bearing Cone Front C1	1	821312100906	73	Piston Ring Set- LP C1	2
33	Bearing Cap Front C1	1	821312100907	74	Piston Ring Set- HP C1	2
34	Seal-Shaft C1	1	821312100911	75	Copper Gasket - Valve Seat C1	10
35	Cap Front C1	1	821312100868	76	Valve Assembly-LP Inlet C1	4
36	Capscrew-Hex M16x120	1	820147149203	77	Valve Assy HP/LP Discharge	4
37	Key Fly Wheel C1	1	821312100928		Gasket Set	1
38	Lockwasher 16	1	820333224300			
39	Nut - Hex M16	1	820261111403			

Warranty Statement

The Company warrants that the Equipment manufactured by it and delivered hereunder shall be free from defects in material and workmanship for a period of twelve (12) months from the date of initial start-up, or eighteen (18) months from the date of shipment from the manufacturer, whichever occurs first. The foregoing warranty period shall apply to all Equipment, except for the following: (A) all two stage reciprocating stationary models are warranted for the earlier of twenty-four (24) months from the date of initial operation or thirty (30) months from date of shipment from the manufacturer. (B) Replacement parts will be warranted for three (3) months from the date of shipment from the manufacturer. Should the failure to conform to this warranty be reported in writing to the Company within said period, the Company shall, at its option, correct such non-conformity by suitable repair to such Equipment, or furnish a replacement part F.O.B. point of shipment, provided that the Purchaser has installed, maintained, and operated such Equipment in accordance with good industry practices, and has complied with specific recommendations of the Company. Accessories and equipment furnished by the Company, but manufactured by others, shall carry whatever warranty the manufacturer conveyed to the Company and which can be passed on to the Purchaser. The Company shall not be liable for any repairs, replacements, or adjustments to the Equipment, or any costs of labor performed by the Purchaser without the Company's prior written approval.

The Company makes no performance warranty unless specifically stated within its proposal, and the effects of corrosion, erosion, and normal wear and tear are specifically excluded from the Company's warranty. In the event performance warranties are expressly included, the Company's obligation shall be to correct in the manner and for the period of time provided above.

This warranty does not apply to electric motors or gasoline engines. These are covered by the Original Manufacturer's Warranty and should be returned (by the customer) to their authorized service center for service..

THE COMPANY MAKES NO OTHER WARRANTY OR REPRESENTATION OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY DISCLAIMED. THIS WARRANTY SUPERSEDES ALL PREVIOUS WARRANTY STATEMENTS.

Correction by the Company of non-conformities, whether patent or latent, in the manner and for the period of time provided above, shall constitute fulfillment of all liabilities of the Company and its distributors for such non-conformities with respect to, or arising out of such Equipment.

LIMITATION OF LIABILITY

THE REMEDIES OF THE PURCHASER SET FORTH HEREIN ARE EXCLUSIVE, AND THE TOTAL LIABILITY OF THE COMPANY, ITS DISTRIBUTORS AND SUPPLIERS WITH RESPECT TO CONTRACT OR THE EQUIPMENT AND SERVICES FURNISHED IN CONNECTION WITH THE PERFORMANCE OR BREACH THEREOF, OR FROM THE MANUFACTURE, SALE, DELIVERY, INSTALLATION, REPAIR OR TECHNICAL DIRECTION COVERED OR FURNISHED UNDER CONTRACT, WHETHER BASED ON CONTRACT, WARRANTY, NEGLIGENCE, INDEMNITY, STRICT LIABILITY OR OTHERWISE, SHALL NOT EXCEED THE PURCHASE PRICE OF THE EQUIPMENT UPON WHICH SUCH LIABILITY IS BASED.

THE COMPANY, ITS DISTRIBUTORS AND ITS SUPPLIERS SHALL IN NO EVENT BE LIABLE TO THE PURCHASER, ANY SUCCESSORS IN INTEREST, OR ANY BENEFICIARY OR ASSIGNEE OF THE CONTRACT FOR ANY CONSEQUENTIAL, INCIDENTAL, INDIRECT, SPECIAL OR PUNITIVE DAMAGES ARISING OUT OF THIS CONTRACT OR ANY BREACH THEREOF, OR ANY DEFECT IN, OR FAILURE OF, OR MALFUNCTION OF THE EQUIPMENT, WHETHER OR NOT BASED ON LOSS OF USE, LOST PROFITS OR REVENUE, INTEREST, LOST GOODWILL, WORK STOPPAGE, IMPAIRMENT OF OTHER GOODS, LOSS BY REASON OF SHUTDOWN OR NON-OPERATION, COST OF PURCHASE OF REPLACEMENT POWER, OR CLAIMS OF PURCHASER OR CUSTOMERS OF PURCHASER FOR SERVICE INTERRUPTION, WHETHER OR NOT SUCH LOSS OR DAMAGE IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, INDEMNITY, STRICT LIABILITY OR OTHERWISE.

Atlas Copco Compressors

1800 Overview Drive
Rock Hill, SC 29730
866-869-3114